



Lift and Tow Z-Bar Parts List

| ITEM | PART NUMBER | DESCRIPTION |
|------|-------------|--|
| 1 | LT-147 | Z-Bar w/ Headplates and Arms. No Cylinders |
| 2 | LT-142 | Z-Bar Bottom Head Plate |
| 3 | LT-436 | Middle Arm Washer |
| 4 | LT-401 | Z-Bar Spring |
| 5 | LT-148 | Left Middle Arm |
| 6 | LT-149 | Right Middle Arm |
| 7 | LT-411 | Shoulder Bronze Bushing 1" x 1 1/4" x 3" |
| 8 | LT-410 | Elbow Bronze Bushing 0.75" x 1" x 2" |
| 9 | LT-138 | Z-Bar Elbow Pin |
| 10 | LT-139 | Z-Bar Shoulder Pin |
| 11 | LT-140 | Z-Bar Cylinder Pin |
| 12 | LT-116 | Left End Arm |
| 13 | LT-117 | Right End Arm |
| 14 | LT-406 | ANSI B18.3 - 3/8-14 UNC x 0.75 |
| 15 | LT-135 | Z-Bar Main 2.5 Inch Pin |
| 16 | LT-403 | Z-Bar Main 2.5 Inch Pin Nut |
| 17 | LT-230 | Z-Bar Cylinder |
| 18 | LT-446 | ANSI B18.2.1 - 5/8-11 UNC - 4.5 |
| 19 | LT-234 | Z-Bar Lock Block w/ Fittings |
| 20 | LT-285 | Z-Bar Cylinder 90 Degree Male Fitting |
| 21 | LT-287 | Z-Bar Cylinder 90 Degree Female Fitting |
| 22 | LT-237 | Single Bend Metal Tubing |
| 23 | LT-100 | Z-Bar Cylinder Seal Kit |
| 24 | LT-423 | 5/8 Hex Nut |
| 25 | LT-428 | Zerk (Grease) Fitting |
| 26 | LT-238 | Triple Bend Steel Tubing |
| 27 | LT-242 | Z-Bar 9.5 Inch Hydraulic Hose |
| 28 | LT-241 | Z-Bar 16.5 Inch Hydraulic Hose |
| 29 | LT-447 | ANSI B18.3 - 3/8-18 UNC 3/8 |
| 30 | LT-143 | Z-Bar Top Head Plate |
| 31 | LT-417 | Chain Hook |

Color is for reference to identify individual parts only.
All fabricated parts are powder coated black.